mr Handsfree®
Blue Music

Bluetooth® stereo headset

GB NL

F RU

User`s manual

DECLARATION OF CONFORMITY

We, the undersigned

Company:	**TE-GROUP nv**
Address:	**Kapelsestraat 61, 2950 Kapellen - BELGIUM**

declare, that the following equipment:

Product Name:	**Blue Music**
Product Type:	**Bluetooth® stereo headset**

is in conformity with the Directions of the European Union

EC R&TTE Directive	1999/5/EC
EC Low Voltage Directive	72/23/EEC
EC EMC Directive	89/338/EEC

Conformity of the Bluetooth® stereo headset with the above-mentioned directions is guaranteed by the CE-symbol.

CE

Illustration I



Illustration II



IMPORTANT REMARKS!

Please read carefully before using your Blue Music headset!

Use of Blue Music headset

- Since Bluetooth® devices produced by different manufacturers provide various functionalities, some functions described in the user manual could be different or not available (Please refer to the manual of your Bluetooth® device for more detailed information).
- Your Blue Music headset can only be paired with Bluetooth® enabled audio devices that have the same pairing PINcode as the Blue Music headset, which is “1234”, or with audio devices of which the pairing PINcode can be changed into “1234”.

Use of Blue Music headset with Bluetooth® PC software or Bluetooth® Dongle

- If you want to use the Blue Music headset with your mobile phone and your PC software simultaneously, please make sure that the Blue Music headset is connected with your mobile phone BEFORE you start using the Blue Music headset together with your PC software.
- The music control wheel feature (see illustration I, n° 1) only works with Microsoft Windows Media Player and your Bluetooth® PC software should support the AVRCP profile. Please refer to your PC software manual for more information or ask your local dealer for more information.
- If you are going to use the Blue Music headset with the mr Handsfree Blue Dongle II (or any other Bluetooth® PC dongle supporting A2DP and AVRCP), it is very important to select the correct setting for your audio connection in the software program of your dongle. Please make sure to select “Bluetooth AV” or “Bluetooth AVRCP” for the audio connection and not the standard “Headset” setting!

TABLE OF CONTENTS

INTRODUCTION 2
GETTING STARTED 2
PAIRING 3
USE WITH MOBILE PHONE 3
USE WITH AUDIO DEVICE 4
USE WITH MOBILE PHONE AND AUDIO DEVICE AT THE SAME TIME 4
TROUBLESHOOTING 5
BLUETOOTH® 5
GUARANTEE 6

INTRODUCTION

The mr Handsfree Blue Music is a Bluetooth® stereo headset, which can be used simultaneously with your Bluetooth® mobile phone and a Bluetooth® A2DP (stereo streaming) enabled audio device (f.e. PC, notebook, PDA, MP3 player, iPod, etc.). The Blue Music headset offers you digital stereo sound and a wireless operating range of up to 10 meters.

Audio devices should support stereo sound by Bluetooth® A2DP profile. If your audio device is non-Bluetooth®, a specially designed Bluetooth® adapter is required. For more information: www.mrhandsfree.com.

GETTING STARTED

OVERVIEW
See illustration I

1. Pairing button / Music control wheel
2. Answer button / Play button
3. Indicator lights
4. Power switch
5. Volume control buttons
6. Microphone
7. Collapsible headband
8. Charging port
9. Power adapter

CHARGING THE BATTERY

The mr Handsfree Blue Music headset comes with a rechargeable battery included. For first time use, it takes about 4 hours to fully charge the battery. Afterwards, it takes about 2 hours to fully charge the battery. When the battery is fully charged, the talk time/listening time is about 6,5 hours and the stand-by time will be about 230 hours.

Make sure that the headset is turned off. → Plug the power adapter (9) into the headset charging port (8). → Plug the other end of the power adapter into an AC outlet. → The red indicator (3) on the headset will light up. → When the battery is fully charged, the red indicator on the headset will turn off.

Note:
You cannot use the Blue Music headset while it is in charging mode.

TURNING THE HEADSET ON/OFF

Use the power switch (4) to turn the power on/off. When the headset is on, the blue indicator (3) is flashing slowly.

WEARING THE HEADSET
See illustration II

The Blue Music headset should be worn as shown in the illustration. The earpiece with the microphone should be located on your right ear.

PAIRING

You are required to pair the Blue Music headset with your mobile phone and/or your Bluetooth® enabled audio device before using it.

Each Blue Music headset has a default PIN-code **1234** for pairing, which is stored in its internal memory. You are usually required to enter the PIN-code **1234** in a pairing process with a Bluetooth® mobile phone or other Bluetooth® devices; however it depends on the kind of Bluetooth® device that the headset is connected to.

The Blue Music headset must be turned on before initiating pairing. → Press and hold the pairing button (1) for 6 seconds until the blue and red indicators (3) of the headset are flashing alternately. → The headset is now ready for pairing. (If you are wearing the headset during the pairing process, you will hear a short tone when the headset is ready for pairing.) → Initiate the pairing process on your Bluetooth® mobile phone or your Bluetooth® enabled audio device to pair with the Blue Music headset (Refer to the manual of your mobile phone/audio device). → You will be asked to enter the PIN-code to complete pairing. Enter **1234** and confirm it. → When the pairing has been successful, the red indicator of the headset will turn off and the blue indicator will flash slowly.

Note:

1. *If the Blue Music headset is not in pairing mode, your mobile phone/audio device won't find the headset. Please set the headset into pairing mode before letting your mobile phone/audio device search for the headset.*
2. *If no pairing is possible for a period of time (approx. two minutes), you may need to start all over again.*
3. *Paired devices remain paired even when:*
   - *One of the devices is not turned on.*
   - *A service connection is interrupted or the service stopped.*
   - *One or both devices are rebooted.*

USE WITH MOBILE PHONE

The mr Handsfree Blue Music is compatible with most Bluetooth® mobile phones. Since Bluetooth® phones produced by different manufacturers provide various functionalities, some functions described in this user's manual could be different or may not be available (Please refer to the manual of your mobile phone for more detailed information).

Once the Blue Music headset is successfully paired with your mobile phone, you can use it to make and receive calls.

MAKING CALLS

Enter and dial the number on the mobile phone as you normally do. → Once the call has been set up, the sound will be transmitted to your headset automatically.

Note:

For some mobile phones, this will take up to 3 seconds.

REDIAL

Press and hold the Volume Down (Vol-) button (5) for 2 seconds to redial the last number you called.

ANSWERING / ENDING CALLS

When the Blue Music headset is turned on and there is an incoming call, you will hear a musical tone. → Press the answer button (2) to answer the call. The sound will be transmitted to your headset automatically. → Press the Volume control buttons (5) to adjust the volume. → End the call by pressing the answer button (2).

Note:
Due to the different design of some mobile phones, an auto-disconnect may happen even when the Blue Music headset is turned on. In that case, the headset won't ring when there is an incoming call. Press and hold the answer button (2) for 2 seconds to reconnect the headset with your mobile phone for an incoming call.

REJECTING CALLS
Press the Reject button on your mobile phone to reject an incoming call.

TRANSFERRING CALLS
Use the power switch (4) to turn the power of the headset off and transfer the call to the mobile phone while talking on the headset.

USE WITH AUDIO DEVICE

The Blue Music headset can also be used with Bluetooth® A2DP enabled audio devices, such as your PC, notebook, PDA, MP3 player, iPod, etc.

Once the Blue Music headset is successfully paired with your audio device, you can use it for listening to your favorite music or for online chatting and gaming.

Audio devices should support stereo sound by Bluetooth® A2DP profile. If your audio device is non-Bluetooth®, a specially designed Bluetooth® adapter is required. For more information: www.mrhandsfree.com.

USE WITH WINDOWS MEDIA PLAYER
Note:
Please refer to your PC software manual for more information or ask your local dealer for more information.

The Blue Music headset includes a special designed music control wheel (1) and a play button (2) that provide you with an easy control to Windows Media Player.

- Play button: to play/pause the music
- Music control wheel:
  - ■ : to stop the music
  - ⏭ : to skip forward
  - ⏮ : to skip back

Note:
The music control wheel is a special feature designed for Windows Media Player only. It does not apply to other audio devices (f.e. MP3 player) since they do not support these functions.

USE WITH MOBILE PHONE AND AUDIO DEVICE AT THE SAME TIME

When the Blue Music headset is paired and connected with your mobile phone and your Bluetooth® enabled audio device, you can use it with both devices simultaneously.

Note:
The use, operation and application of this function depend on the specific model of mobile phone that has been paired with the Blue Music headset! Refer to the Bluetooth® chapter in the manual of your mobile phone.

MAKING CALLS WHILE LISTENING TO MUSIC

Enter and dial the number on the mobile phone as you normally do. ➞ Once the call has been set up, the headset will automatically mute the music.

ANSWERING / ENDING CALLS WHILE LISTENING TO MUSIC

When the Blue Music headset is turned on and there is an incoming call, you will hear a musical tone. ➞ The headset will automatically mute the music and the audio channel will be switched to your mobile phone. ➞ Press the answer button (2) to answer the call. ➞ Press the Volume control buttons (5) to adjust the volume. ➞ End the call by pressing the answer button (2). ➞ The audio channel will be switched back to the audio device and the music will start playing again.

TROUBLESHOOTING

1. No indication of charging is shown.	For the headset battery that is empty, or has not been used for a long time, it may take a couple of minutes for the headset indicator to show charging status with a steady red light.
2. No sound contact between the Blue Music headset and other devices.	- Make sure that the two devices have been paired. - Make sure that the headset is turned on. - Make sure that the two devices are within a working range. - Make sure that your mobile phone is within signal strength. - Some Bluetooth® mobile phones can support only one Bluetooth® headset. Disconnection may happen when there is more than one headset paired with your mobile phone.
3. Several Bluetooth® devices appear on my mobile phone while searching the Blue Music headset.	Most Bluetooth® enabled mobile phones with Bluetooth® function activated can search for more than one Bluetooth® device within operative range. The Blue Music headset will appear as “Blue Music” or “Unknown Device” on your mobile phone after having been found by your mobile phone.
4. There is a disturbance noise coming from the Blue Music headset.	The performance of the headset will be affected by two factors: - Whether your mobile phone is in a good signal area. If your mobile phone is in a week signal area, you won’t hear clearly with the headset. - Whether it is in the operative range.

BLUETOOTH®

The *Bluetooth*® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by TE-Group NV is under license. Other trademarks and trade names are those of their respective owners.

GUARANTEE

Mr Handsfree is a registered trademark of TE-Group NV.

The mr Handsfree brand stands for superior product quality and outstanding customer service. That is why mr Handsfree warrants this product against all defects in material and workmanship for a period of **two (2) years** from the date of original purchase of the product.

The conditions of this limited guarantee and the extent of responsibility of mr Handsfree under this limited guarantee are as follows:

- This guarantee is limited to the original purchaser of the product and is not transferable to any subsequent purchaser/end user.
- During the limited guarantee period, the sole responsibility of mr Handsfree will be limited to repair or replace, at its option, any defective parts of the product if this is needed because of malfunction or failure under normal use and conditions. No charge shall be made to the customer for parts and/or repair labor.
- The product must be shipped to an authorized service center in its original and complete packaging, with transportation charges prepaid. Mr Handsfree will not assume responsibility for any losses or damages during transportation.
- To obtain repair or replacement within the terms of this guarantee, the customer must provide (a) a proof of purchase (e.g. dated bill of sale); (b) a written specification of the defect(s); (c) a return address and phone number.
- This limited guarantee does not cover and is void with respect to the following:
  (a) Products which have been subjected to improper installation, unauthorized repair, improper maintenance, unauthorized modifications or other acts which are not the fault of mr Handsfree; (b) Products which have been subjected to misuse, abuse, neglect, improper handling and storage, an accident or physical damage; (c) Products which have been subjected to fire, water, excessive humidity, sand, dirt, extreme changes in temperature or other conditions which are beyond the control of mr Handsfree; (d) Products which have been used with non-mr Handsfree approved accessories; (e) Products which have the serial number altered, defaced or removed; (f) Products which have been opened, altered, repaired or modified by any unauthorized service center.
- Excluded from any guarantee are consumable items which may need replacing due to normal wear and tear, such as batteries, headset ear cushions, decorative parts and other accessories.
- This limited guarantee gives you specific legal rights, and you may also have other rights which vary from country to country.

Waste electrical products must not be disposed of with household waste. This equipment should be taken to your local recycling centre for safe treatment.

Copyright by TE-Group nv - Belgium